PLEASE NOTE--

If the amplifier or hi-fi used with the MINI-SYNTHESIZER does not have a three-prong, grounded AC power plug, you may notice that the synthesizer's sound becomes impure when the pitch bend slider is all the way down. Sometimes this "AC hum" can be corrected by reversing the power plug in the wall socket. If this does not solve the problem, it is necessary to establish a ground between the amplifier or hi-fi and the wall socket. For this purpose, an insulated wire of sufficient length with spade lugs on both ends can be obtained at electronic and electrical supply stores or hardware outlets. Secure one end of the wire to the central screw on the wall socket, and the other end to the amplifier. Some hi-fi's have a screw marked "GROUND" or "GND" for this purpose. Otherwise, any screw which contacts the metal chassis of the amplifier can be used.

Warranty

For complete warranty information, consult your warranty/registration card. In the event that it should become necessary to return this unit to the factory for repair, please incule $7.50 (£3.75 in the U.K.) to cover the costs of handling and return shipping.

MINI SYNTHESIZER

operating instructions

ELECTRO HARMONIX

NEW YORK: 27 West 23rd Street, New York, N.Y. 10010
LONDON: Unit F24, Park Hall Trading Estate, Martell Road SE21
TORONTO: 379 Adelaide St. West, Suite 202, Toronto, Ont. M5V1S5
TOKYO: 1-34 Koshiji Bldg., Jinbocho, Chiyoda-Ku, Tokyo

MADE IN U.S.A.